










Macintosh
Setup Poster
安装海报

HP Deskjet 6800 series






Step 1: Set up the printer hardware

步骤 1：安装打印机硬件



Step 2: Connect to the printer

步骤 2：连接打印机



3

Verify Network light is on. If not, check cable connections.
检查“网络”指示灯是否亮起。若未亮起，请检查电缆的连接。

4

Insert CD, double-click the CD icon, and then double-click the installer icon.
放入 CD，连接 CD 图象，然后连接安装器图象。

5

When prompted by the setup assistant, remove the Ethernet cable from the printer and the network hub, switch, or router.
在设置助理提示时，从打印机和网络集线器、交换机，或路由器拔下以太网电缆。

6

Use the CD to install the printer software on each computer that will use the printer.
使用 CD 在每一台要使用该打印机的计算机上安装打印机软件。

Need help?
需要帮助?

Network Guide
网络指南

Reference Guide
参考指南

www.hp.com/support

Ethernet

Verify that the network is set up, powered on, and functioning properly.
检查并确认网络已设置、电源打开，且操作正确。

1

Use the included Ethernet cable to connect the printer to the network hub, switch, or router.
使用随附的以太网电缆，将打印机连接到网络集线器、交换机，或路由器。

2

Verify that the Network light is on. If not, check the cable connections.
检查“网络”指示灯是否亮起。若未亮起，请检查电缆的连接。

3

Insert CD, double-click the CD icon, and then double-click the installer icon.
放入 CD，连接 CD 图象，然后连接安装器图象。

4

Use the CD to install the printer software on each computer that will use the printer.
使用 CD 在每一台要使用该打印机的计算机上安装打印机软件。

USB

Connect printer to computer. Insert CD, double-click the CD icon, and then double-click the installer icon.
将打印机连接到计算机。放入 CD，连接 CD 图象，然后连接安装器图象。

Printer buttons and lights
打印机按钮和指示灯

1. Power button and light
2. Cancel button
3. Resume button and light
4. Report Page button
5. Wireless Status light
6. Signal Strength indicator
7. Print Cartridge Status lights
8. Network light

1. “电源”按钮和指示灯
2. “取消”按钮
3. “继续”按钮和指示灯
4. “报告页”按钮
5. “无线状态”指示灯
6. “信号强度”指示器
7. “打印墨盒状态”指示灯
8. “网络”指示灯

Use the Report Page button to print an HP Report page.
使用“报告页”按钮打印“HP 报告”页。

6